smartctl Disk health check

Find drive --scan, lsblk → `-i / -H` → **Check health** verdict + attributes → `-t short|long` → **Self-test** runs inside the drive → `-l selftest` → **Read the log** pass or first bad LBA

CONCEPTS

Run as root. Without it most commands fail with a permission error on the device node.

PASSED only means no attribute has crossed its failure threshold. A drive can still be dying: watch reallocated, pending and uncorrectable sectors.

Device is the whole disk, such as /dev/sda or /dev/nvme0, not a partition like /dev/sda1.

INFORMATION AND HEALTH

`smartctl --scan`
List devices smartctl can see

`smartctl -i` *<dev>*
Model, serial, firmware, capacity

`smartctl -H` *<dev>*
Overall health: PASSED or FAILED

`smartctl -A` *<dev>*
Vendor attributes (NVMe: health log)

INFORMATION AND HEALTH (cont.)

`smartctl -a` *<dev>*
Info, health, attributes, error and test logs

`smartctl -x` *<dev>*
Extended: all of -a plus device stats, SCT data

`smartctl -c` *<dev>*
Drive SMART capabilities

`smartctl -H -q errorsonly` *<dev>*
Print only on problems (for scripts)

`smartctl -j -a` *<dev>*
JSON output for tools like jq

`smartctl -s on` *<dev>*
Enable SMART on the drive

SELF-TESTS

`smartctl -t short` *<dev>*
Quick test, usually a few minutes

`smartctl -t long` *<dev>*
Full surface test, minutes to hours

`smartctl -l selftest` *<dev>*
Show self-test results

`smartctl -X` *<dev>*
Abort a running self-test

SELF-TESTS (cont.)

Self-tests run on the drive itself and are non-captive by default, so the disk stays usable. Check back with -l selftest after the estimated time.

LOGS AND ERRORS

`smartctl -l error` *<dev>*
Drive error log

`smartctl -l xerror` *<dev>*
Extended error log, more entries (ATA)

`smartctl -l scterc` *<dev>*
Show error recovery timeouts (ATA)

DEVICES AND NVME

`smartctl -d` *<type>* *<dev>*
Force the device type

`smartctl -d sat` *<dev>*
USB or SATA bridge (SCSI-to-ATA)

`smartctl -a /dev/nvme0`
NVMe health log: spare, wear, temperature

`smartctl -d megaraid,`*<n>* **`/dev/sda`**
Disk n behind a MegaRAID controller

DEVICES AND NVME (cont.)

NVMe paths: /dev/nvme0 is the controller, /dev/nvme0n1 a namespace. Both normally work with -a.

READING ATTRIBUTES

Attributes worth watching (ATA)

ID / name	Concern when
`5 Reallocated_Sector_Ct`	raw above 0 and rising
`187 Reported_Uncorrect`	raw above 0
`197 Current_Pending_Sector`	raw above 0 (unread sectors)
`198 Offline_Uncorrectable`	raw above 0
`199 UDMA_CRC_Error_Count`	rising: suspect cable or port
`194 Temperature_Celsius`	sustained above ~55 C

READING ATTRIBUTES (cont.)

Health log fields (NVMe)

Field	Concern when
Critical Warning	not 0x00
Available Spare	near Threshold
Percentage Used	approachir 100%
Media and Data Integrity Errors	above 0
Temperature	sustained above ~70 C

In the -A table, a normalized VALUE falling to its THRESH means failing; the RAW column is vendor-specific and often counts something other than you expect.

A rising pending-sector count that later turns into reallocations is the classic sign of a failing disk. Back up first, test later.

SCRIPTING AND OPTIONS

`smartctl -n standby` *<dev>*
Skip the check if the drive is asleep