nvidia-smi GPU monitoring

nvidia-smi summary table → `-q / --query-gpu` → **Detail or CSV** pick fields → `-l / dmon` → **Live monitor** loop or stream → `-pm / -pl` → **Tuning** needs root

CONCEPTS

Run with no arguments first: the table shows driver and CUDA versions, temperature, power, memory and processes per GPU.

Anything that changes state (persistence, power, clocks, reset) needs root and usually does not survive a reboot.

The GPU index order can differ from CUDA_VISIBLE_DEVICES order; use UUIDs for stable targeting.

INSPECT

nvidia-smi
Show GPU summary table

nvidia-smi -L
List GPUs with UUIDs

nvidia-smi -q
Show all details for every GPU

nvidia-smi -i *<id>*
Limit output to one GPU

nvidia-smi -q -d MEMORY,UTILIZATION
Show only chosen sections

INSPECT (cont.)

nvidia-smi -q -x
Print details as XML

nvidia-smi -f *<file>* **-q**
Write output to a file

nvidia-smi --version
Show tool and driver version

nvidia-smi -h
Print help

MONITOR

nvidia-smi -l *<sec>*
Repeat every N seconds

nvidia-smi -lms *<ms>*
Repeat every N milliseconds

nvidia-smi dmon
Stream power, temp, clocks, load

nvidia-smi dmon -s um
Choose metric groups to stream

nvidia-smi pmon
Show load per process

nvidia-smi pmon -s um
Per-process utilization and memory

nvidia-smi dmon -c *<n>*
Stop after N samples

watch -n 1 nvidia-smi
Refresh the table in place

SCRIPTED QUERIES

nvidia-smi --query-gpu=*<fields>* **--format=csv**
Query chosen fields as CSV

nvidia-smi --query-gpu=name,memory.used,memory.total --format=csv
Memory use per GPU

nvidia-smi --query-gpu=temperature.gpu --format=csv,noheader,nounits
Bare numbers for scripts

nvidia-smi --query-compute-apps=pid,process_name,used_memory --format=csv
Compute processes and memory

nvidia-smi --help-query-gpu
List every queryable field

nvidia-smi --query-gpu=*<fields>* **--format=csv -l 1**
Log CSV every second

nvidia-smi --query-supported-clocks=gr,mem --format=csv
List supported clock pairs

nvidia-smi --help-query-compute-apps
List compute-app fields

PERSISTENCE AND COMPUTE MODE

sudo nvidia-smi -pm 1
Enable persistence mode

sudo nvidia-smi -c *<mode>*
Set compute mode

sudo nvidia-smi -r
Reset the GPU

sudo nvidia-smi -e *<0|1>*
Disable or enable ECC

POWER AND CLOCKS

sudo nvidia-smi -pl *<watts>*
Set power limit

sudo nvidia-smi -lgc *<min>,<max>*
Lock GPU clock range in MHz

sudo nvidia-smi -rgc
Unlock GPU clocks

sudo nvidia-smi -lmc *<min>,<max>*
Lock memory clock range in MHz

sudo nvidia-smi -rmc
Unlock memory clocks

nvidia-smi -q -d CLOCK
Show current and max clocks

POWER AND CLOCKS (cont.)

nvidia-smi -q -d PERFORMANCE
Show throttle reasons

TOPOLOGY AND OTHERS

nvidia-smi topo -m
Show GPU interconnect matrix

RECIPES

Log GPU load to a CSV

```
nvidia-smi --query-gpu=
timestamp,utilization.gpu,
memory.used,power.draw \
  --format=csv,noheader -l 5
>> gpu.csv
```

Who is using the GPU?

```
nvidia-smi --query-compute-
apps=pid,used_memory --
format=csv,noheader
ps -o pid,user,cmd -p <pid>
```

Prepare a shared box

```
sudo nvidia-smi -pm 1
sudo nvidia-smi -pl 250
nvidia-smi -q -d POWER |
head -20
```

Watch one GPU in a terminal

```
nvidia-smi -i 0 -l 1 \
  --query-gpu=temperature.
gpu,utilization.gpu,memory.
used --format=csv
```