nvidia-smi GPU monitoring

START HERE

nvidia-smi
GPU summary

nvidia-smi pmon
Per-process usage

nvidia-smi -L
List GPUs and UUIDs

nvidia-smi dmon
Rolling metrics

nvidia-smi -l 2
Refresh every 2 s

nvidia-smi topo -m
Link topology

nvidia-smi -q
Full detail dump

nvidia-smi -i *<id>* **-q**
One GPU only

nvidia-smi summary table → **-q / --query-gpu** → **Detail or CSV** pick fields → **-l / dmon** → **Live monitor** loop or stream → **-pm / -pl** → **Tuning** needs root

CONCEPTS

Run with no arguments first: the table shows driver and CUDA versions, temperature, power, memory and processes per GPU.

Anything that changes state (persistence, power, clocks, reset) needs root and usually does not survive a reboot.

The GPU index order can differ from CUDA_VISIBLE_DEVICES order; use UUIDs for stable targeting.

INSPECT

nvidia-smi
Show GPU summary table

nvidia-smi -L
List GPUs with UUIDs

nvidia-smi -q
Show all details for every GPU

nvidia-smi -i *<id>*
Limit output to one GPU
<id> is an index, UUID, serial or PCI bus ID. Works with most options.

nvidia-smi -q -d MEMORY,UTILIZATION
Show only chosen sections
Other types: ECC, TEMPERATURE, POWER, CLOCK, PERFORMANCE.

nvidia-smi -q -x
Print details as XML

nvidia-smi -f *<file>* **-q**
Write output to a file

nvidia-smi --version
Show tool and driver version

nvidia-smi -h
Print help

MONITOR

nvidia-smi -l *<sec>*
Repeat every N seconds

MONITOR (cont.)

nvidia-smi -lms *<ms>*
Repeat every N milliseconds

nvidia-smi dmon
Stream power, temp, clocks, load

nvidia-smi dmon -s um
Choose metric groups to stream
Groups: p power/temp, u utilization, c clocks, v violations, m memory, e ECC, t PCIe.

nvidia-smi pmon
Show load per process

nvidia-smi pmon -s um
Per-process utilization and memory

nvidia-smi dmon -c *<n>*
Stop after N samples

watch -n 1 nvidia-smi
Refresh the table in place

SCRIPTED QUERIES

nvidia-smi --query-gpu=*<fields>* **--format=csv**
Query chosen fields as CSV

nvidia-smi --query-gpu=name,memory.used,memory.total --format=csv
Memory use per GPU

nvidia-smi --query-gpu=temperature.gpu --format=csv,noheader,nounits
Bare numbers for scripts

nvidia-smi --query-compute-apps=pid,process_name,used_memory --format=csv
Compute processes and memory

nvidia-smi --help-query-gpu
List every queryable field

nvidia-smi --query-gpu=*<fields>* **--format=csv -l 1**
Log CSV every second

SCRIPTED QUERIES (cont.)

nvidia-smi --query-supported-clocks=gr,mem --format=csv
List supported clock pairs

nvidia-smi --help-query-compute-apps
List compute-app fields

PERSISTENCE AND COMPUTE MODE

sudo nvidia-smi -pm 1
Enable persistence mode
Keeps the driver loaded so launches are faster. Resets on reboot; NVIDIA recommends the persistence daemon.

sudo nvidia-smi -c *<mode>*
Set compute mode
DEFAULT, EXCLUSIVE_PROCESS or PROHIBITED. Resets on reboot.

sudo nvidia-smi -r
Reset the GPU
Fails if processes still use the GPU.

sudo nvidia-smi -e *<0|1>*
Disable or enable ECC
Takes effect after a reboot or reset.

sudo nvidia-smi -am 1
Turn on process accounting

POWER AND CLOCKS

sudo nvidia-smi -pl *<watts>*
Set power limit
Must stay within the range shown by -q -d POWER.

sudo nvidia-smi -lgc *<min>,<max>*
Lock GPU clock range in MHz

sudo nvidia-smi -rgc
Unlock GPU clocks

sudo nvidia-smi -lmc *<min>,<max>*
Lock memory clock range in MHz

POWER AND CLOCKS (cont.)

sudo nvidia-smi -rmc
Unlock memory clocks

nvidia-smi -q -d CLOCK
Show current and max clocks

nvidia-smi -q -d PERFORMANCE
Show throttle reasons

TOPOLOGY AND OTHERS

nvidia-smi topo -m
Show GPU interconnect matrix
Shows NVLink, PCIe and CPU affinity between devices.

nvidia-smi nvlink -s
Show NVLink status

nvidia-smi mig -lgi
List MIG GPU instances
MIG is Ampere and newer; enabling it needs -mig 1 plus a reset.

nvidia-smi -mig 1
Enable MIG mode

nvidia-smi drain -h
Show GPU drain options

RECIPES

Log GPU load to a CSV

```
nvidia-smi --query-gpu=
timestamp,utilization.gpu,
memory.used,power.draw \
  --format=csv,noheader -l 5 >>
gpu.csv
```

Who is using the GPU?

```
nvidia-smi --query-compute-
apps=pid,used_memory --
format=csv,noheader
ps -o pid,user,cmd -p <pid>
```

Prepare a shared box

```
sudo nvidia-smi -pm 1
sudo nvidia-smi -pl 250
nvidia-smi -q -d POWER | head
-20
```

Watch one GPU in a terminal

```
nvidia-smi -i 0 -l 1 \
  --query-gpu=temperature.gpu,
utilization.gpu,memory.used --
format=csv
```